


Screamer Mods

TS9 / TS808 Switch

Sym. / Asym. Clipping



- R16 und R15 leer lassen
- leave R15 and R16 empty